



### **Installs As Easy As 1-2-3**



**There's no need to remove the winches from the trailer. Just fit OverDrive onto the winch cap.**



**Insert the heavy-duty cap securing cross-pin.**



**Insert the cross-pin securement bolt, add the locking nut... and you're done!**